

# Somfy Wirefree Li-ion Charger (V2)

## INSTALLATION INSTRUCTIONS



### SAFETY INSTRUCTIONS

Use of this appliance is not recommended by children under the age of 8 years old. Persons with reduced capabilities, knowledge or experience should seek professional advice and instruction prior to use.

### PRE-CAUTIONS

- Keep away (Minimum 1 Meter) from all type of flames, sparks or incandescent material.
- Do not open the charger, risk of electric shock.
- Do not use the charger if the cable is damaged.
- Do not cover during use.
- Do not recharge batteries other than Li-ion batteries recommended by Somfy.

### CHARGING COMPATIBILITY

#### Item Number Motors with External Li-ion Battery

9021217	External Li-ion Battery Pack <i>(charger to connect to charging plug of ext. battery)</i>
1003293	Tilt & Lift 25 RTS Central
1241163	Altus 28 WF RTS 1.5/28 w/o ext. Li-ion Battery V2

#### Item Number Motor with Internal Li-ion Battery

1240486	Sonnesse 40 WF RTS Li-ion 3/28
1240512	Sonnesse 30 WF RTS Li-ion-12mm (V2)
1241151	ALTUS 28 WF (WF) RTS 1.5/28 Li-ion (Int. Battery) V2

### TECHNICAL DATA

Item Number	9025165
Battery Type	Rechargeable Lithium Li-ion
Rechargeable Battery Capacity	2600 mAh
Charger Cable Length	4m

### INSTALLATION INSTRUCTIONS


A



Connect the WireFree Li-ion Charger mains wall plug into the Wall Socket.

Please ensure that the mains voltage complies with local standards (240V).

B




Connect the charging plug into the motor / battery pack.

The LED light on the mains wall plug will illuminate red (indicating the device is charging).

**\*Do not force plug into motor, ensure connector is correctly inserted**

C



When the battery is fully charged, the LED light on the mains wall plug will illuminate green.

Once the device is fully charged, disconnect the charger from the device as well as the mains wall plug.