

# Somfy Wirefree Li-ion Charger (V2)

## INSTALLATION INSTRUCTIONS



### SAFETY INSTRUCTIONS

Use of this appliance is not recommended by children under the age of 8 years old. Persons with reduced capabilities, knowledge or experience should seek professional advice and instruction prior to use.

### PRE-CAUTIONS

- Keep away (Minimum 1 Meter) from all type of flames, sparks or incandescent material.
- Do not open the charger, risk of electric shock.
- Do not use the charger if the cable is damaged.
- Do not cover during use.
- Do not recharge batteries other than Li-ion batteries recommended by Somfy.

### CHARGING COMPATIBILITY

#### Item Number Motors with External Li-ion Battery

|         |  |
|---------|--|
| 9021217 | External Li-ion Battery Pack<br><i>(charger to connect to charging plug of ext. battery)</i> |
| 1003293 | Tilt & Lift 25 RTS Central   |
| 1241163 | Altus 28 WF RTS 1.5/28 w/o ext. Li-ion Battery V2  |

#### Item Number Motor with Internal Li-ion Battery

|         |  |
|---------|--|
| 1240512 | Soness 30 WF RTS Li-Ion-12mm (V2)                    |
| 1241151 | ALTUS 28 WF (WF) RTS 1.5/28 Li-ion (Int. Battery) V2 |

### TECHNICAL DATA

|                               |                             |
|-------------------------------|-----------------------------|
| Item Number                   | 9025165                     |
| Battery Type                  | Rechargeable Lithium Li-ion |
| Rechargeable Battery Capacity | 2600 mAh                    |
| Charger Cable Length          | 4m                          |

### INSTALLATION INSTRUCTIONS


A



Connect the WireFree Li-ion Charger mains wall plug into the Wall Socket.

Please ensure that the mains voltage complies with local standards (240V).

B




Connect the charging plug into the motor / battery pack.

The LED light on the mains wall plug will illuminate red (indicating the device is charging).

**\*Do not force plug into motor, ensure connector is correctly inserted**

C



When the battery is fully charged, the LED light on the mains wall plug will illuminate green.

Once the device is fully charged, disconnect the charger from the device as well as the mains wall plug.